

# LV-682


---

## Mini-ITX motherboard

### User's Manual

Edition: 1.00

2008/02/01



## **Copyright**

The trademarks mentioned in the manual are legally registered to their respective companies.

## **Disclaimer**

### Notice

The written content provided with this product is the property of Taiwan Commate. No part of this manual may be reproduced, copied, transmitted in any form or by any means without prior written permission of Taiwan Commate.

### Manual Classification

In order to assist in the use of this product, Taiwan Commate has categorized the user manual. For detailed product information and specifications, please carefully read the “ Product User Manual ”.

## **Trademark**

All trademarks are the property of their respective holders.

---

Any questions please visit our website at <http://www.commell.com.tw>.

## Packing List

---

Please check package component before you use our products.

- ☆ LV - 682 board
- ☆ Quick Installation Guide
- ☆ CD for manual and drivers
- ☆ Cable Kit (CPU cooler, IDE cable, Serial ATA cable, Serial Port cable, I/O Shield, Power cable)

# Table Of Contents

## General Information

< Introduction >.....	5
< Specification>.....	錯誤! 尙未定義書籤。
< Block Diagram>.....	9
<Mechanical Drawing >.....	9

## Hardware Installation

<Connector Location>.....	12
< List of Connectors >.....	13
<Jumper Locations>.....	14
< List of Jumpers>.....	14
< Jumpers Setting>.....	15
< LVDS Panel Voltage Selection ( JP1 ) >.....	15
< Clear CMOS Selection ( JU5 ) >.....	15
<COM2 RS232/422/485 Slection ( JP3, JP2 )>.....	16
<LVDS Connector ( CN2 )>.....	17
< VGA & AUDIO Connector ( CN5 )>.....	17
< GPIO Connector ( CN6 ) >.....	18
< COM3 RS-232 Connector ( CN8 ) >.....	18
< COM4 RS-232 Connector ( CN9 )>.....	18
< Front Panel Connector ( CN10 ) >.....	19
< EIDE Connector Connector ( J4 ) >.....	19
< PS2 KB/ MS Connector ( J5 ) >.....	20
< CPU Fan Connector ( J7 ) >.....	20
< System Fan Connector ( J8 ) >.....	20
< ATX Power Connector ( J9 ) >.....	20
< Slim Floppy Connector ( J11 ) >.....	21
< COM1 RS-232 Connector ( COM1 Down ) >.....	22
< COM1 RS-232 Connector ( COM1 Up )>.....	22

< USB1 Connector ( USB1 ) >.....	22
< USB2 Connector ( USB2 ) >.....	22
< CompactFlash Slot ( CFD1 ) >.....	22
< SoDIMM Slot ( DIMMA1 ) >.....	22
< SoDIMM Slot ( DIMMA2 ) >.....	23
< Mini - PCI Slot ( MPC11 ) >.....	23
<PCI-E Gigabit LAN / USB Connector ( RJUSB1 A / B )>.....	23
<PCI-E Gigabit LAN / USB Connector ( RJUSB1 A / B ) >.....	23
<SATA1 Connector ( SATA1 ) >.....	23
<SATA2 Connector ( SATA2 ) >.....	23

## BIOS Setup

<AwardBIOS CMOS Setup Utilit>.....	24
<Main CMOS Features>.....	24
<Advanced BIOS Feature>.....	26
<Power Management Setup>.....	27
<PnP / PCI Configurations>.....	28
<Peripherals Setup>.....	29
<PC Health Status>.....	31
<Boot Status>.....	32
<Save & Exit Setup>.....	33
<Load Optimized Defaults>.....	33
<Exit Without Saving>.....	33
<Set Password>.....	33

## Appendix

<Watch Dog timer Setting > .....	34
----------------------------------	----

# General Information

## Introduction

The LV-682 Mini – ITX board incorporates the ATI RS690E + ATI RS600chipset, supports the AMD Turion 64 / Sampron uPGA 638 Pin processors with 800 MHz Front Side Bus (FSB), The RS690E integrates an ATI RADEON X-1250-based 2D/3D graphics engine, dual display, The SB600 is a south bridge that integrates key I/O, communications, and audio features. The board supports DDRII 667MHz system memory, PCI interface, PCI-E Gigabit LAN, Audio, LVDS, DVI Compact Flash, Mini – PCI, Serial ATA, USB 2.0, COM, IEEE 1394.

## Multimedia Applications

For multimedia application solution, ATI RS690E chipset provides on board high performance graphics, 24 – bit LVDS interface, DVI and Audio function. This feature will be good of use in very requirement of the multimedia application.

## Widely Expanded Interface

The board provides PCI slot, you can add a third LAN port, and also provides Mini – PCI slot and Compact Flash Type II slot.

# Specification

Board	LV-682 Mini - ITX
CPU	AMD Mobile Turion 64x2 638-pin Processor Sempron 638-pin Processor
Chipset	AMD RS690E + SB600
Memory	2 DDR II SoDIMM slot support DDR II 533 / 667 MHz SDRAM Up to 4GB
VGA	Built in AMD RS690E chipset
I / O Control	AMD SB600 + ITE 8712 + Fintek F81216D
LAN	2 Realtek RTL8111B 10 / 100 / 1000Mbit PCI-Express Giga LAN
Audio	AMD SB600 with Realtek ALC655 Codec
IDE	1 44Pin UDMA 33 connection
SATA	2 Serial ATA II 3.0 Gbit/sec ports
Slot	1 Mini – PCI slot 1 CompactFlash slot 1 PCI slot
BIOS	AMI 4Mb PnP Flash
GPIO	16 – bit digital I / O
Green Function	ACPI 1.0 and APM 1.2 compliant
Watchdog Timer	System reset programmable watchdog timer with 1 ~ 255 sec. of time - out
H / W Monitoring	ITE 8712 support power supply voltage and temperature monitoring functions
Real Time Clock	AMD SB600 built – in RTC with Lithium battery
Form Factor	Mini – ITX 6.69 “( L ) x 6.69” ( W ) / 17 x 17 mm

# VGA Display

---

Chipset	AMD RS690E chipset
Memory	Shared system memory up to 256M
Display	CRT / LCD monitor with analog for 24 – bit LVDS interface
DVI	Support DVI display

---

## Internal I/O Ports

---

GPIO	1 GPIO Port Connector
USB	2 USB Connector Supports 4 USB ports
Serial Port	2 RS-232 Connector, COM3 with 5V power COM4 with 12V power
CDIN	1 CDIN Connector
Audio	1 Audio Connector
IEEE1394	1 IEEE 1394 Connector
IDE	1 44-Pin IDE Connector
LVDS	1 24-Bit LVDS Connector
Inverter	1 LCD Inverter Connector
DVI	1 DVI
FAN	2 FAN Connector

---

## External I/O Ports

---

Keyboard/ Mouse	1 PS / 2 ports
Serial Ports	1 external RS–232 port ( COM 1 ) with 5V power 1 external RS–232 / 422 / 485 port ( COM 2 ) with 12V power
VGA	1 VGA port
Audio	1 external jack for MIC – In / Line – In / Line – Out
LAN	2 external RJ – 45 ports with LED
USB	4 external USB 2.0 ports

---



# Power And Environment

---


POWER	ATX 20-Pin power connector OR 8~21V full range 4 –Pins DC adapter
-------	--

---


TEMPERATURE	Operating temperature with 0°C~60°C (32°F~140°F) Storage temperature with 20°C~80°C (-68°F~176°F)
-------------	--

---


## 1.3 <Block Diagram>



# 1.4 <Mechanical Drawing >




# Solder Side




# Hardware Installation

## Connectors Location


### Component Side



# Solder Side



## I / O Panel



MOUSE	COM2	VGA OUT	LAN2	LAN1	DC IN
KEYBOARD	COM1	AUDIO OUT IN MIC	USB1 USB0	USB3 USB2	8V~20V

## Connectors

Connector	Function
CN2	LVDS Connector
CN3	DVI
CN4	CD-IN Connector
CN5	VGA & AUDIO Connector
CN6	GPIO Connector
CN8	COM3 RS-232 Connector
CN9	COM4 RS-232 Connector
CN10	Front Panel Connector
CN11	Front audio Connector
CN12	LVDS Inverter Power Connector
CN13	1394 Connector
J1	SATA1 Connector
J2	SATA2 Connector
J5	PS2 Keyboard / Mouse Connector
J7	CPU Fan Connector
J8	System Fan Connector
J9	ATX Power Connector


---

J10	4 Pin Power Connector 12V limited 0.8A Output 5V limited 1A Output
J11	PCI Slot
JP4	DC Power Jack Connector
CFD1	CompactFlash Socket
COM1 Down	COM1 RS-232 Connector
COM1 Up	COM2 RS-232 / RS-422 / RS-485 Connector
DIMMA1	SoDIMM Slot
DIMMB1	SoDIMM Slot
IDE1	44pin IDE Connector
MPCI1	Mini - PCI Slot
RJUSB1 A / B	PCI-E Gigabit LAN / USB Connector
RJUSB2 A / B	PCI-E Gigabit LAN / USB Connector
USB1	USB1 Connector
USB2	USB2 Connector

---



# Jumpers Locations



# List of Jumpers

---

J3 CF card Master / Slave

---

JP1 LVDS Panel Voltage Selection (+5V / + 3.3V )

---

JP2 COM2 RS232/422/485 Select

---

JP3 COM2 RS232/422/485 Select

---

JU5 Clear CMOS Selection

---


JU6 COM2 12V Voltage Select

---


JU7 COM1 5V Voltage Select

---


## Jumpers Setting




## LVDS Panel Voltage Selection ( JP1 )




## Clear CMOS Selection ( JU5 )









## COM2 Pin 9 Selection ( JU6 )



## COM1 Pin 9 Selection ( JU7 )
























## CF Card Master/Slave Selection ( J3 )

Master			Slave		
					
1	2	3	1	2	3

## COM2 RS232/422/485 Selection ( JP3,JP2 )

COM2 SETTING RS232

JP3				JP2			
1				1			
4				3			
7				5			
10							





---

**COM2 SETTING RS422**

---

JP3

JP2

1 □ 2   31   24 ○ 5   63   47 ○ 8   95   610 ○ 11   12





---

**COM2 SETTING RS485**

---

JP3

JP2

1 □ 2   31   24 ○ 5   63   47 ○ 8   95   610 ○ 11   12

---

## DC Power Jack Connector ( JP4 )

Pin	Assignment	Pin	Assignment
1	+12V	2	GND
3	GND	4	N/C
5	ENABLK		

## LVDS Connector ( CN2 )

Pin	Assignment	Pin	Assignment
1	VCC	2	VCC
3	GND	4	GND
5	TXU0N	6	TXL0N
7	TXU0P	8	TXL0P
9	GND	10	GND
11	TXU1N	12	TXL1N
13	TXU1P	14	TXL1P
15	GND	16	GND
17	TXU2N	18	TXL2N
19	TXU2P	20	TXL2P
21	GND	22	GND
23	TXU3N	24	TXLCKN
25	TXU3P	26	TXLCKP
27	GND	28	GND
29	TXUCKN	30	TXL3N
31	TXUCKP	32	TXL3P
33	GND	34	GND
35	N/C	36	I2C_CLK
37	N/C	38	I2C_DATA

39	N/C	40	N/C
----	-----	----	-----

## DVI Connector ( CN3 )

Pin	Assignment	Pin	Assignment
1	TX1P	2	TX1N
3	GND	4	GND
5	TXCP	6	TXCN
7	GND	8	PVDD
9	N/C	10	N/C
11	TX2P	12	TX2N
13	GND	14	GND
15	TX0P	16	TX0N
17	N/C	18	HPD
19	SDA	20	SCL
21	GND	22	N/C
23	N/C	24	N/C
25	N/C	26	N/C

## VGA Display Connector ( CN5 )

Pin	Assignment	Pin	Assignment
1	RED	2	GREEN
3	BLUE	4	N / C
5	GND	6	GND
7	GND	8	GND
9	VGA_VCC	10	GND
11	N / C	12	CRT_DDCDATA
13	HSYNC	14	VSYNC
15	CRT_DDCCLK		

## GPIO Connector ( CN6 )

Pin	Assignment	Pin	Assignment
1	GPIO1-2	2	GPIO1-1
3	GPIO1-4	4	GPIO1-3
5	GPIO1-6	6	GPIO1-5
7	GPIO1-8	8	GPIO1-7
9	GPIO1-10	10	GPIO1-9
11	GPIO1-12	12	GPIO1-11
13	GPIO1-14	14	GPIO1-13
15	GPIO1-16	16	GPIO1-15
17	GND	18	+5V



## COM 3 RS-232 Connector ( CN8 )

Pin	Assignment	Pin	Assignment
1	DCD3#	2	RXD3
3	TXD3	4	DTR3#
5	GND	6	DSR3#
7	RTS3#	8	CTS3#
9	RI3#	10	N / C

## COM4 RS-232 Connector ( CN9 )

Pin	Assignment	Pin	Assignment
1	DCD4#	2	RXD4
3	TXD4	4	DTR4#
5	GND	6	DSR4#
7	RTS4	8	CTS4#
9	RI4#	10	N / C

## Front Panel Connector ( CN10 )

Pin	Assignment	Pin	Assignment
1	GND	2	Power Switch
3	BUZZER-	4	BUZZER+
5	HD_LED-	6	HD_LED+
7	POWER LED-	8	Power LED+
9	GND	10	Reset

## Front Audio Connector ( CN11 )

Pin	Assignment	Pin	Assignment
1	Front-R	2	Front-L
3	Surround-R	4	Surround-L
5	LFEOUT	6	CENOUT
7	SPDIFO-N	8	SPDIFI-N
9	GND	10	GND

## LVDS Inverter Power Connector ( CN12 )

Pin	Assignment	Pin	Assignment
1	+12V	2	GND
3	LVDS_BLON	4	CPIS_BLEN
5	+5V		

## IEEE 1394 Connector ( CN13 )

Pin	Assignment	Pin	Assignment
1	PWR	2	GND
3	TPB0-	4	TPB0+
5	TPA0-	6	TPA0+
7	GND	8	N/C

## PS2 KB / MS Connector ( J5 )

Pin	Assignment	Pin	Assignment
1	KB_DATA	2	N / C
3	GND	4	KB_VCC
5	KB_CLK	6	N / C
7	MS_DATA	8	N / C
9	GND	10	KB_VCC
11	MS_CLK	12	N / C

## CPU Fan Connector ( J7 )

Pin	Assignment
1	GND
2	12V
3	FAN Sense

## System Fan Connector ( J8 )

Pin	Assignment
1	GND
2	12V
3	FAN Sense

# ATX Power Connector ( J9 )

Pin	Assignment	Pin	Assignment
1	3.3V	2	3.3V
3	GND	4	5V
5	GND	6	5V
7	GND	8	N / C
9	5VSB	10	12V
11	3.3V	12	-12V
13	GND	14	PSON
15	GND	16	GND
17	GND	18	-5V
19	5V	20	5V

## 4 Pin Power Connector ( J10 )

Pin	Assignment
1	12V( Yellow ) Limited 0.8A Output
2	GND
3	GND
4	5V ( Red ) Limited 1A Output

## COM1 RS-232 Connector (COM1 DOWN)

Pin	Assignment	Pin	Assignment
1	DCD1#	2	RXD1
3	TXD1	4	DTR1#
5	GND	6	CSR1#
7	RTS1#	8	CTS1#
9	RI1#		

## COM2 RS-232/422/485 Connector (COM1 UP)

Pin	Assignment	Pin	Assignment
1	DCD2#(422TXD-/485DATA-)	2	RXD2(422RXD+)
3	TXD2(422TXD+/485DATA+)	4	DTR2#(422RXD-)
5	GND	6	DSR2#
7	RTS2#	8	CTS2#
9	RI2#		

## USB Connector (USB1, USB2)

Pin	Assignment	Pin	Assignment
1	USB_VCC	2	GND
3	USB4-	4	GND
5	USB4+	6	USB5+
7	GND	8	USB5-
9	GND	10	USB_VCC

## **CompactFlash Slot ( CFD1 )**

Standard CompactFlash Connector Type II

## **Mini-PCI Slot (MPCI1)**

Standard Mini-PCI Connector

## **PCI-E Gigabit LAN / USB Connector ( RJUSB1 )**

Standard RJ - 45 Connector / Standard USB Connector

## **PCI-E Gigabit LAN / USB Connector ( RJUSB2 )**

Standard RJ - 45 Connector / Standard USB Connector

## **SATA1 Connector ( J1 )**

Standard Serial ATA Connector

## **SATA2 Connector ( J2 )**

Standard Serial ATA Connector

## **CD-IN Connector ( CN4 )**

Standard CD-IN Connector

## **EIDE Connector ( J4 )**

Standard 44-pin EIDE Connector

## **PCI Connector ( J11 )**

Standard 120-pin PCI Slot Connector

# BIOS Setup

## BIOS SETUP UTILITY

**Main** Advanced PCIPnP Boot Security Chipset Power  
Exit

### System Overview

#### AMIBIOS

Version :08.00.14  
Build Date :06/14/07  
ID :08.00.14

#### Processor

AMD Turion™ 64x2 Mobile Technology TL-56  
Speed :1800MHz  
Count :2

#### System Memory

size :1984MB  
System Time [ 14:20:34 ]  
System Date [ Sat  
06/16/2007 ]

Use [ENTER], [TAB]  
or [SHIFT-TAB] to  
Select a field.  
Use [+] or [-] to  
Configure system  
Time.

← Select  
Screen  
↑ ↓ Select Item  
+ - Change Field  
Tab Select Field  
F1 General Help  
F10 Save and  
Exit  
ESC Exit

### Time

Hour 00 to 23  
Minute 00 to 59  
Second 00 to 59

**Date**

Day Sun to Sat  
Month Jan. through Dec.  
Date 1 to 31  
Year 1999 through 2099

# BIOS SETUP UTILITY

**Main** **Advanced** PCIPnP Boot Security Chipset  
**Power** **Exit**

<b>Advanced Settings</b>	Option for CPU
CPU Configuration	
IDE Configuration	
SuperIO Configuration	← Select Screen
Hardware Health Configuration	↑ ↓ Select Item
ACPI Configuration	Tab Select Field
USB Configuration	F1 General Help
	F10 Save and Exit
	ESC Exit



# BIOS SETUP UTILITY

## Advanced

<b>CPU Configuration</b>		
Gart Error Reporting	[ Disabled ]	← Select Screen
Microcode Update	[ Enabled ]	↑ ↓ Select Item
SVM uCode Option	[ Enabled ]	+ - Change Field
Runtime Legacy PSB	[ Disabled ]	F1 General Help
ACPI 2.0 Objects	[ Enabled ]	F10 Save and Exit
Maximum Frequency during Post	[ Enabled ]	ESC Exit

### **CPU Configuration**

BIOS version

This items show the CPU information,

of your system ( read only ).

# BIOS SETUP UTILITY

## Advanced

IDE Configuration		
OnBoard PCI IDE Controller	[ Primary ]	← Select Screen
Primary IDE Master	[ Not Detected ]	↑ ↓ Select Item
Primary IDE Slave	[ Not Detected ]	+ - Change Field
		F1 General Help
		F10 Save and Exit
		ESC Exit
Hard Disk write Protect	[ Disabled ]	
IDE Detext Time Out (sec)	[ 35 ]	
ATA(PI) 80pin cable Detection	[ Host&Device ]	

**Primary Master / Slave**  
controller.

Enables only the primary IDE

**Hard Disk Write Protect**  
accessed

This will be effective only if device is  
through BIOS.

**IDE Detext Time Out (sec)**

Select the time out value for detecting  
ATA/ATAPI devices.

**ATA(PI) 80pin cable Detection**  
80pin

Select the mechanism for detecting  
ATA(PI) cable.

# BIOS SETUP UTILITY

## Advanced

### Configure ITE8712 Super IO Chipset

Serial Port1 Address	[ 3F8/IRQ4 ]
Serial Port1 Mode	[ Normal ]
Serial Port2 Address	[ 2F8/IRQ3 ]
Serial Port2 Mode	[ Normal ]
Serial Port3 Address	[ 3E8 ]
Serial Port3 IRQ	[11 ]
Serial Port4 Address	[ 2E8 ]
Serial Port4 IRQ	[ 10 ]

←	Select Screen
↑ ↓	Select Item
+ -	Change Field
F1	General Help
F10	Save and Exit
ESC	Exit

**Serial Port1 Address**  
base

Allows BIOS to select serial port1  
address.

**Serial Port1 Mode**  
port1.

Allows BIOS to select mode for serial

**Serial Port2 Address**  
base

Allows BIOS to select serial port2  
address.

**Serial Port2 Mode**  
port2.

Allows BIOS to select mode for serial

**Serial Port3 Address**  
base

Allows BIOS to select serial port3  
address.

**Serial Port3 Mode**  
IRQ.

Allows BIOS to select serial port3

**Serial Port4 Address**  
base

Allows BIOS to select serial port4  
address.

**Serial Port4 Mode**  
IRQ.

Allows BIOS to select serial port4

# BIOS SETUP UTILITY

## Advanced

<b>Hardware Health Configuration</b>		Enables hardware Health Monitoring Device.
Hardware health Function	[ Enabled ]	
Temperature Sensor #1	[ Enabled ]	
Temperature Sensor #1	[ Enabled ]	
Fan1 speed	[ Enabled ]	
Fan2 speed	[ Enabled ]	
Hardware health Function	[ Enabled ]	
		← Select Screen
		↑ ↓ Select Item
		+ - Change Field
		F1 General Help
		F10 Save and Exit
		ESC Exit

### PC Health

This option allows you to see the temperature

Monitoring function feature of the board. The

Values are read-only as monitored by the

system and show the PC health status.

# BIOS SETUP UTILITY

## Advanced

### ACPI Settings

General ACPI Configuration  
Advanced ACPI Configuration

← Select Screen  
↑ ↓ Select Item  
+ - Change Field  
F1 General Help  
F10 Save and Exit  
ESC Exit

# BIOS SETUP UTILITY

## Advanced

### General ACPI Configuration

Suspend mode [ Auto ]  
Repost video on S3 Resume [ No ]  
C1E Support [ Disabled ]

General ACPI  
Configuration settings.

← Select Screen  
↑ ↓ Select Item  
+ - Change Field  
F1 General Help  
F10 Save and Exit  
ESC Exit

**Suspend mode**  
system suspend.

Select the ACPI state used for

**Repost video on S3 Resume**  
post on

Determines whether in voke VGA BIOS  
S3/STR resume.

# BIOS SETUP UTILITY

## Advanced

Advanced ACPI Configuration		
ACPI Version Features	[ ACPI V1.0 ]	← Select Screen
ACPI APIC Support	[ Enabled ]	↑ ↓ Select Item
AMI OEMB	[ Enabled ]	+ - Change Field
Headless Mode	[ Disabled ]	F1 General Help
		F10 Save and Exit
		ESC Exit

**ACPI Version Features**

Enable RSDP points to 64-bit.

**ACPI APIC Support**

point lists.

Include ACPI APIC table pointer to RSDT

**AMI OEMB**

point lists.

Include OEMB table pointer to RSDT

**Headless Mode**  
mode through

Enable/Disable Headless operation  
ACPI.

# BIOS SETUP UTILITY

## Advanced

USB Configuration	
Legacy USB support	[ Enabled ]
USB 2.0 Controller Mode	[ HiSpeed ]
BIOS EHCI Hand-Off	[ Enabled ]

← Select Screen  
↑ ↓ Select Item  
+ - Change Field  
F1 General Help  
F10 Save and Exit  
ESC Exit

**Legacy USB support**  
Option.  
device are

Enable support for legacy USB. Auto  
Disables legacy support if no USB  
connected.

**USB 2.0 Controller Mode**  
fullspeed(12Mbps).

Configures the USB 2.0 controller in  
Hispeed(480Mbps) or

**BIOS EHCI Hand-Off**  
EHCI

This is workaround for OS without  
hand-off support. The EHCI

ownership chang

should claim by EHCI driver.



# BIOS SETUP UTILITY

Main Advanced **PCIPnP** Boot Security Chipset  
Power Exit

Advanced PCI/PnP Settings	
---------------------------	--

Clear NVRAM	[ No ]	
Plug & Play O/S	[ No ]	
PCI Latency Timer	[ 64 ]	
Allocate IRQ to PCI VGA	[ Yes ]	
Palette Snooping	[ Disabled ]	
PCI IDE BusMaster	[ Enabled ]	
Off Board PCI/ISA IDE card	[ Auto ]	
IRQ3	[ Available ]	
IRQ4	[ Available ]	
IRQ5	[ Available ]	
IRQ7	[ Available ]	
IRQ9	[ Available ]	
IRQ10	[ Available ]	
IRQ11	[ Available ]	
IRQ14	[ Available ]	
IRQ15	[ Available ]	
DMA Channel0	[ Available ]	
DMA Channel1	[ Available ]	← Select
DMA Channel3	[ Available ]	Screen
DMA Channel5	[ Available ]	↑ ↓ Select Item
DMA Channel6	[ Available ]	Tab Select Field
DMA Channel7	[ Available ]	F1 General
Reserved memory size	[ Disabled ]	Help
		F10 Save and
		Exit
		ESC Exit

### Clear NVRAM

Clear NVRAM during system boot.

### Plug & Play O/S

Lets the BIOS configure all the device

in the

system

**PCI Latency Timer**  
driver

Value in units of PCI clocks for PCI

Latency timer register.

**Allocate IRQ to PCI VGA**  
request IRQ.

Assigns IRQ to PCI VGA card if card

**Palette Snooping**  
device is

Informs the PCI device on ISA graphics

installed in the system,so the card will

function.

**PCI IDE BusMaster**  
device.

BIOS use PCI busmaster for R/W to IDE

**Off Board PCI/ISA IDE card**

Works for most PCI IDE card.

# BIOS SETUP UTILITY

Main Advanced PCIPnP **Boot** Security Chipset  
Power Exit

**Boot Settings**

<p>Booting Settings Configuration          Boot Device Priority          Removable Drivers</p>	<p>Configure setting during System boot.</p>       <p>←      Select Screen          ↑ ↓    Select Item          Tab    Select Field          F1     General Help          F10    Save and Exit          ESC    Exit</p>
--	--

**BIOS SETUP UTILITY**

**Boot**

<b>Boot Settings Configuration</b>	
------------------------------------	--

Quick Boot	[ Enabled ]	Allows BIOS to Skip Certain tests while booting. This will decrease the time needed to boot the system.
Quiet Boot	[ Disabled ]	
Add on Rom Display Mode BIOS ]	[ Force	
Bootup Num-lock	[ On ]	
PS/2 Mouse support	[ Auto ]	
Interrupt 19 Capture	[ Disabled ]	
		← Select Screen
		↑ ↓ Select Item
		Tab Select Field
		F1 General Help
		F10 Save and Exit
		ESC Exit

**Quick Boot**  
while booting.

Allows BIOS to skip certain tests

**Quiet Boot**  
boot the

This will decrease the time needed to

message.

system. Displays normal POST

**Add on Rom Display Mode**

Set display mode for option ROM.

**Bootup Num-lock**

Select power-on state for numlock

**PS/2 Mouse support**

Select support for PS/2 mouse.

**Interrupt 19 Capture**

Allows option ROMS to trap interrupt 19.

# BIOS SETUP UTILITY

Main Advanced PCIPnP Boot **Security** Chipset  
Power Exit

<b>Security Settings</b>	
Change Supervisor Password	← Select Screen
Change User Password	↑ ↓ Select Item
Boot sector virus Protection [ Disabled ]	Tab Select Field
	F1 General Help
	F10 Save and Exit
	ESC Exit

# BIOS SETUP UTILITY

Main Advanced PCIPnP Boot Security **Chipset**  
Power Exit

<b>Chipset configuration</b>	
NorthBridge Configuration	
SouthBridge Configuration	← Select Screen
AMD 690T Configuration	↑ ↓ Select Item
OnBoard Peripheral Configuration	Tab Select Field
	F1 General Help
	F10 Save and Exit
	ESC Exit

# BIOS SETUP UTILITY

## Chipset

NorthBridge Chipset configuration		I
Memory Configuration		← Select Screen
		↑ ↓ Select Item
		Tab Select Field
Power down control	[ Auto ]	F1 General Help
		F10 Save and Exit
		ESC Exit

### Power down control

mode by

when DIMMs

Allows DIMMs to enter power down

deasserting the clock enable signal

are not in use.

# BIOS SETUP UTILITY

## Chipset

### Memory Configuration

Memclock Mode	[ Auto ]	←	Select Screen
MCT Timing Mode	[ Auto ]	↑ ↓	Select Item
Bank Interleaving	[ Auto ]	+ -	Change Field
Enable Clock to all DIMMs	[ Disabled ]	F1	General Help
Memclk tristate C3/ATLVID	[ Disabled ]	F10	Save and Exit
DQS Signal Training Control	[ Enabled ]	ESC	Exit
Memory Table remapping	[ Enabled ]		

#### Memclock Mode

programming

Select the DRAM frequency

be base

method, if Auto the DRAM speed will

on SPDs.

#### Bank Interleaving

which

If Auto the memory will be checked

executes 64 or 128-bits mode

#### Enable Clock to all DIMMs

memory slots

Enable Unused clocks to DIMMs even

are not populated.

#### Memclk tristate C3/ATLVID

C3 and

Enable/Disable Memclk Tri-stating during

ATLVID.

#### DQS Signal Training Control

memory timing

Turing this off will require custom

programming. Training will be



automatically disabled

if CS sparing is enable.

**Memory Table remapping**  
memory hole.

Enable memory remapping around

## BIOS SETUP UTILITY

### Chipset

#### SouthBridge Chipset Configuration

AC 97 Audio device	[ Enabled ]
USB 1.1 OHCI controllers	[ Enabled ]
USB 2.0 EHCI controller	[ Enabled ]
OnChip SATA Channel	[ Enabled ]
OnChip SATA Type	[ Native
IDE ]	

## BIOS SETUP UTILITY

### Chipset

#### AMD 690T Configuration

Internal Graphics Configuration

PCI Express Configuration

# BIOS SETUP UTILITY

## Chipset

### Internal Graphics Configuration

Internal Graphics mode	[ UMA ]
UMA Frame buffer size	[ 64MB ]
Graphics clock mode	[ SYNC ]
GFX engine clock	[ 200 ]
Multifunction	[ Disabled ]
Primary Video controller	
[ PCIE/IGFX/PCI ]	
Video Display Devices	[ Auto ]
TV standard	[ NTSC ]
Expansion mode	[ Disabled ]

←	Select Screen
↑ ↓	Select Item
+ -	Change Field
F1	General Help
F10	Save and Exit
ESC	Exit

# BIOS SETUP UTILITY

Main Advanced PCIPnP Boot Security Chipset  
Power Exit

Power Configuration		
Power Management/APM	[ Enabled ]	
Suspend Time Out	[ Disabled ]	
Power Button Mode	[ On/Off ]	
Video Power Down Mode	[ suspend ]	
Hard Disk time out(Minute)	[ Disabled ]	
Restore On AC Power Loss	[ Disabled ]	
RTC Resume	[ Disabled ]	

**Power Management/APM**  
management

Enable/Disable SMI based power  
and APM support.

**Suspend Time Out**  
BIOS will

If no activity during this time period the

state.

place the system into suspend low power

are not populated.

**Power Button Mode**

Select Power button functionality.

# BIOS SETUP UTILITY

Main Advanced PCIPnP Boot Security Chipset  
Power **Exit**

Exit Options	
Save Changes and Exit	
Discard Changes and Exit	
Discard changes	
Load Optimal Defaults	
Load Failsafe Defaults	

**Save Changes and Exit**  
changes.

Exit system setup after saving

**Discard Changes and Exit**  
changes.

Exit system setup without saving any

**Discard changes**  
the setup

Discard changes done so for to any of  
questions

**Load Optimal Defaults**

Load Optimal default values for all the setup  
questions.

**Load Failsafe Defaults**

Load Failsafe default values for all the setup  
questions.

# Appendix

## Watchdog Timer

User could test watchdog timer function under “ DEBUG.EXE  
“ program as follows:

<b>DEBUG</b>	<b>Description</b>
O 2e 87	
O 2e 01	
O 2e 55	
O 2e 55	
O 2e 07	
O 2f 07	
O 2e 72	
O 2f c0	<b>C0: second ( 40: minute )</b>
O 2e 72	
O 2e 73	<b>Control second or minute</b>
O 2f 00 ~ FF	<b>O 2f 08 ( 8 second reset )</b>